

Poudre School District MiFi Terms and Conditions, and Instructions

When a family/student accepts a MiFi, they **agree to the terms and conditions of use and return** of the equipment:

- Student use of District information technology is a privilege, not a right, and is **only authorized for education-related purposes**.
- Student use of District information technology shall be in accordance with [District policy JS - STUDENT USE OF DISTRICT INFORMATION TECHNOLOGY](#). By accepting the MiFi device, the family and student **agree to comply with the terms and conditions included in District policy JS**.
- Student authorization to use District information technology shall be terminated **when the student is no longer enrolled in a District school or program**.
- MiFi devices are property of Poudre School District and must be returned if the device is no longer needed, a student withdraws from Poudre School District, and no later than by the last week of the current school year. Families may be charged for damaged/lost/non-returned MiFi devices.

TURN ON THE MIFI


1. To **power on** (or to turn off) the **MiFi** device, **press and hold the power button for 3 seconds**, or until the screen activates or deactivates. **Tip:** *The power button is located on the front of the device.*



FIND THE MIFI NAME (SSID) AND PASSWORD

1. Once the **MiFi** is powered on, **tap the power button to go through the options**.
2. The **second and third options** show the **WiFi name and Password**.


CONNECT TO THE MIFI:



1. **Open the wireless connections on your device**. The **MiFi** wireless will be named by the **PSD Barcode** (ex: PSD123456).
2. Once you find this, click the **"Connect"** button and **verify Connect automatically is checked**.
3. Enter the **Password for the MiFi** in the space provided (**A**) and **click 'Next' (B)**.



Note: *If asked to allow your PC to be discoverable, click 'No' to continue.*



4. **You're All Set!** Your device is now connected and has access to the internet. **Up to 5 devices, used for educational purposes only, can be connect at once**, but you may see reduced speeds with each added device.

Still Have Questions? Please reach out to your **School** for further troubleshooting and additional assistance.